

ASSEMBLY INSTRUCTIONS

MASSAGE RECLINER CHAIR



Approximate Assembly Time



People Required to Assemble



No Extra Tools Required




Before you start...

Please carefully unpack and lay out all of the component parts to ensure nothing is missing and to check each component for any obvious damage.









Should you identify any concerns at this stage please contact the retailer from whom this product was purchased. Please quote your order number, details of your issue, the product code, and the batch number from the cartons which will help to resolve your issue as quickly as possible.

Version Number - 1.0

**Product Code - MAL006
MAL005**



No Extra Tools
Required.



Contact Retailer

Please check all hardware matches the list below. Should you notice any are missing please contact your retailer.




A

1X



B

18X



C

M8X37mm

18X



D

M6x20mm

8X



E

M8x25mm

2X



F

2X



G


1X



H

M5

1X



I

M6

1X




J

1X



K

1X




L

4X

We strongly advise that you do not use Power Tools, such as drills or electric screwdrivers during the assembly as this may cause irreparable damage and will invalidate your warranty.



PARTS



A	1X
B	18X
C	18X
D	8X
E	2X
F	2X
G	1X
H	1X
I	1X
J	1X
K	1X
L	4X

1	1X
2	2X
3	4X
4	5X
5	1X
6	1X
7	1X

Please ensure you carefully check all the pieces, should you have any concerns please contact the retailer before assembly commences. Please have your order number, details of the issue, the product code, and the batch number from the cartons as this will help us to resolve your issue much faster.

ASSEMBLY ADVICE

Please take the time to carefully read through these instructions before you commence.

Keep these instructions for future reference.

We advise that the product is assembled in the room it is intended for.

We advise that you keep the hardware in a bowl during assembly to avoid losing anything.

We strongly recommend that you keep children away from the work area.

Small component parts could choke a child if swallowed.

We recommend you use a sheet or blanket to protect both floor and product through the assembly stages.


This product is heavy, and we recommend a 2 person lift to avoid personal injury or damage to the product.

Never push or pull the product as this could cause both personal injury or irreparable damage to product or floor.


We have tried to make this piece of furniture easy to assemble if the instructions are followed carefully.

In the unlikely event that you have problems with assembling the product or have missing or damaged parts, please contact your retailer and we will assist them in rectifying the problem as quickly as possible.


Please remember we strongly urge you DO NOT use power tools such as drill or electric screwdrivers as this could cause irreparable damage to your product and will invalidate your warranty.




1




2




3




4



5




6



7



Massage Chair Functions



- Press the ON/OFF button to switch the massage unit on. The massage unit will start in Mode 1 and will automatically shut down after 15 minutes if no other button is pressed. Press the ON/OFF button again whilst in the massage mode to switch off the unit.
- Press the HEAT button to switch the heat function on. The HEAT light will be lit when this function is on. Press the HEAT button again to switch the heat function off.
- Press the MODE button to select the massage mode. The current massage mode is shown by one of the five MODE lights being illuminated.
- Press the INTENSITY button to increase the intensity of the massage vibrations. After pressing the button, the new intensity will be shown momentarily by illuminating one of the INTENSITY lights. Once the intensity is at maximum, pressing the button again will reset the intensity to its lowest level.

GENERAL CARE & MAINTENANCE

We advise that when cleaning the product that a damp cloth is used.

Avoid the use of all household cleaners and abrasive.

Never push or drag the furniture.

Never attempt to move the furniture when fully loaded.

We advise that periodically all fixing are re-tightened.

DISPOSAL REQUIREMENTS UNDER WEEE REGULATIONS




Figure 1: WEEE symbol – crossed out wheeled bin

For private households: Information on Disposal for Users of WEEE

This symbol (figure 1) on the product(s) and/ or accompanying documents means that used electrical and electronic equipment (WEEE) should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product(s) to designated collection point where it will be accepted free of charge. Alternatively, in some countries, you may be able to return your products to your local retailer upon purchase of an equivalent new product

Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling

Please contact your local authority for further details of your nearest designated collection point

Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation

For professional users in the European Union

If you wish to discard electrical and electronic equipment (EEE), please contact your dealer or supplier for further information

For disposal in countries outside of the European Union

This symbol is only valid in the European Union (EU). If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.