






3 Drawer Chest


Assembly Instructions





Customer Service
(01623 727374)

HARDWARE



A

M 5 x 50mm
15x



B

M 3 x 13mm
36x



C

M 4 x 18mm
12x



D

Ø 6 x 24
37x



E

Ø 15 x 12
37x



F

Ø 8 x 30
18x



G

M 3 x 19mm
12x



H

Ø 15
4x




I

Ø 17
12x



J

128 mm
6x




K

566 mm
1x




L1L

400mm
3x




L1R

400mm
3x




L2L

400mm
3x



L2R

400mm
3x



M

M 3 x 19mm
1x



N



Ø 10mm
1x



O

1x

PARTS



Safety Advice

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check off all of the contents.

Please dispose of all packaging safely.

Small component parts could choke a child if swallowed.

We strongly recommend that you keep children well away from the work area.

It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and to protect your floor.


This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

Assemble the product as close to its intended final position in the room as possible.


HANDY HINT: If you keep the hardware in a bowl during assembly you will be less likely to lose them.

WARNING: In order to prevent overturning this product must be used with the wall attachment device provided.


1




2



3




4




5

STEP 1





REPEAT
X3


STEP 2



REPEAT
X3




STEP 3




REPEAT
X3


STEP 1




STEP 2




STEP 3



STEP 4




STEP 4




REPEAT
X3

6


STEP 5




7




STEP 1



STEP 2




STEP 3




8



STEP 1




STEP 2



STEP 3




9




10



STEP 1



STEP 2





STEP 3




11


X12 PCS (G)



12




13



14

ADDITIONAL SAFETY INFORMATION

In the interest of safety, particularly where small children are concerned, we advise securing your furniture to the wall to prevent the product from tipping forwards when loaded. The screw included in this fitting pack is only intended for fixing the safety strap to the piece of furniture. Use fixing devices suitable for the walls in your home, (NOT INCLUDED). If you are unsure what type of fixings to use, please seek further advice from your local DIY store.



Your 3 Drawer Chest is now ready for use.

General Care

Wipe clean with a slightly damp soft cloth.

Avoid the use of all household cleaners and abrasives.

When moving your furniture, carefully lift into place.

Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

Recommendations

Periodical re-tightening of fixings.

Warning

This unit is heavy. Please use an assistant when lifting.

Notes

We've tried to make this piece of furniture as easy to assemble as possible.

In the unlikely event that you have problems putting it together or have damaged or missing pieces.

please contact our customer services on 01623 727374