


Before you start....

Please carefully unpack and lay out all of the component parts to ensure nothing is missing and to check each component for any obvious damage.


Should you identify any concerns at this stage please contact the retailer from whom this product was purchased. Please quote your order number, details of your issue, the product code, and the batch number from the cartons which will help to resolve your issue as quickly as possible.

Version Number - 1.0

Product Code - NOV002



Please check all hardware matches the list below. Should you notice any are missing please contact your retailer.






Plastic Ø17 x 04

We strongly advise that you do not use Power Tools, such as drills or electric screwdrivers, during the assembly as this may cause irreparable damage and will invalidate your warranty.





ASSEMBLY ADVISE

Please take the time to carefully read through these instructions before you commence.

Keep these instructions for furure reference.

We advise that the product is assembled in the room it is intended for.

We advise that you keep the hardware in a bowl during assembly to avoid losing anything.

We strongly recommend that you keep childrem away from the work area.

Small component parts could choke a child if swallowed.

We recommend you use a sheet a blanket to protect both floor and product through the assembly stages.

This product is heavy, and we recommend a 2 person lift to avoid personal injury or damage to the product.

Never push or pull the product as this could cause both personal injury or irreparable damage to product or floor.


We have tried to make this piece of furniture easy to assemble if the instructions are followed carefully.


In the unlikely event that you have problems with assembling the product or have missing or damaged parts, please contact your retailer and we assist them in rectifying the problem as quickly as possible.


PLEASE


Remember we strongly urge you DO NOT use power tools such as drill or eletric screwdrivers as this could cause irreparable damage to your product and will invalidate your warranty











GENERAL CARE & MAINTENANCE

We advise that when cleaning the product that a damp cloth is used.

Avoid the use of all household cleaners and abrasive.

Never push or drag the furniture.

Never attempt to move the furniture when fully loaded.

We advise that periodically all fixings are re-tightened.